

ARIAN WELD DOUBLE WAGE



ARIAN WELD




Arian Weld

With the help and grace of Almighty God, Arian Weld Company informs its customers that for the welfare of your loved ones, Arian Weld manufactures Arian Weld machines and other devices related to polyethylene and PVC welding. These machines are equipped with fully automatic industrial equipment, including lathes, CNC milling machines, wire cutting, laser cutting, etc. The best high-quality materials are used to manufacture the machine parts.



Instructions:

- 1. First, connect the device to the city electricity or generator.
- 2. The display turns on and off after a few seconds. Press the left key (POWER-ON/OFF) to turn on the display.
- 3. The next key (M) toggles the engine on and off.
- 4. The third key (-) decreases the engine speed.
- 5. The fourth key (+) increases the engine speed.
- 6. The + and keys are also used to adjust the temperature. Press the H (heat) button until the arrow appears on the temperature number, then use the + and keys to adjust the heat. Press H and + simultaneously to increase the temperature.







To maintain the device:

- 1. After using the device, clean and rotate the rollers and lubricate the rail drawer with grease spray.
- 2. Avoid operating the device under the following conditions:
 - Power fluctuations
 - High humidity environment
 - Inappropriate project conditions
- 3. Arin Weld device comes with a 1-year warranty.
- 4. The warranty does not cover:
 - Device fire
- Accidental dropping and breakage of the device
- Connection to three-phase electricity circuits.

